

Class Tuning Guides

Base Rig Settings

Headstay	Mast Step	J	Pre-bend	V1	D1	D2
2.26	0.46	4.025	0.02	55 Units	40 Units	20 Units

Headstay length is measured by pulling genoa halyard down front of mast to top of black band. Swing out and mark extrusion. Measure from mark to deck next to furling drum.

Mast step location is measured from aft face of bulkhead to front face of mast. Step is max forward.

J dimension measured from forward face of mast to stem/sheerline intersection.

Shroud tension measured with RT-10 Loos guage.

Shroud Adjustment

TWS (Knots)	V1	D1	D2
5-to-10	-4	-2	-2
10-to-15	Base	Base	Base
15-to-20	3	2	2

One Design Downwind Targets

TWS	TWA	Boat Speed	AWS	AWA
6	140.9	4.98	3.75	84.02
8	143.7	6.01	4.68	94.37
10	149.5	6.48	5.4	112.02
12	159.8	6.63	6.06	137.57
14	170.8	6.92	7.06	161.83
16	175.5	7.36	8.46	171.52
20	176.5	8.22	11.54	174.05

PHRF Downwind Targets

TWS	TWA	Boat Speed	AWS	AWA
6	140.9	5.04	3.78	83.56
8	143.8	6.04	4.69	94.38
10	149.7	6.5	5.4	112.45
12	159.9	6.66	6.08	137.89
14	168.7	6.98	7.16	157.76
14	168.7	6.98	7.16	157.76
16	172.7	7.41	8.56	166.35
20	173.8	8.25	11.7	169.45

One Design Upwind Targets

TWS	TWA	Boat Speed	AWS	AWA
6	44.4	4.73	9.75	24.51
8	43.2	5.66	12.42	24.74
10	41.7	6.14	14.64	24.67
12	40.3	6.34	16.67	24.95
14	39.3	6.46	18.61	25.35
16	38.8	6.53	20.49	25.84
20	38.8	6.59	24.12	27.17

PHRF Upwind Targets

TWS	TWA	Boat Speed	AWS	AWA
6	45	5.02	9.98	24.07
8	43.5	5.85	12.53	24.21
10	41.3	6.2	14.7	24.32
12	39.8	6.37	16.72	24.62
14	38.9	6.49	18.66	25.03
16	38.4	6.56	20.54	25.54
20	38.4	6.56	24.16	26.87